

User Manual

WODPLAYER4K is one of the powerful
OTT Media Player IP **Set-top-box** (STB)



Preface

Please read and follow the instructions carefully in order to use World on Demand smoothly. This setup guide will make it easier to operate the set top box provided.

Statement

World on Demand has made every possible effort to provide the most current information about the product.

The instructions mentioned here is intended to enable the correct usage of the product.

We reserve rights to introduce amendments, changes or translations of the user manual without prior notification. For this reason, we recommend you to visit our website, www.worldondemand.net, timely in order to obtain the latest information.

Contents

1. What box includes?	02
2. What is World on Demand?	03
3. Requirement for usages of World on Demand on TV	03
4. How to connect World on Demand to TV?	03
5. How do I login into the system?	03
6. Launcher	04
6.1 Live TV	06
6.2 Movies	07
6.3 TV Shows	07
6.4 Youtube Plus.	07
6.5 Video Chautari	07
6.6 Highlights Nepal.	07
6.7 My Account	08
7. Detailed description of remote	09
8. Payment Method.	10
9. How do I connect WiFi in the World on Demand STB?	10
10. General Troubleshooting Tips	10

What box includes?



Set Top Box (STB)



Remote Controller



HDMI Cable



Adapter


2. What is World on Demand?

Harness the power of your internet connection and take your media experience to a new level. It is called IPTV- TV through the internet. It puts you in total control of your TV and entertainment. Watch what you want, when you want. And above all- stay connected to your community. World on Demand is the first TV Channels Network for World Community residing abroad.

3. Requirement for the usages of World on Demand on TV

Internet connectivity
HDMI Cable
World on Demand STB

4. How to connect World on Demand to TV?



5. How do I login into the system?

If you are a first time user then you need to do quick signup for a World On Demand Account by filling up the Signup form carefully. Open 'My Account' App from Launcher > It will ask for Signup Form as shown below :

Email : This will be your username so ensure that you have entered the correct email ID

Display Name : This will appear as your Name in STB Launcher so ensure that you provide the correct full name.

Box ID : It will appear automatically if you are our valid STB User.


Password : It must be your Login Password so make sure that you are using it securely. It must be minimum of 6 Digit.

Confirm Password : You will have to Re-type your password in this field.

Currency : Choose your preferred currency for purchases.

Once you have successfully registered the account and logged into the system, you can choose the desired feature that you want to watch and enjoy the services provided by World on Demand.


6. Launcher



- Timezone : Displays the timezone that the box is currently in
- Time: Displays the current time of the device
- Day,Date: Displays the current day and date
- Network Status: Displays the network status, whether it is connected to Ethernet or Wifi
- Box ID: Displays the unique ID (Mac ID) of the box
- Version: Displays the current version of the launcher
- Build: Displays the build of the set top box
- IP : Displays the IP address of the box that it is currently connected to

i. Side Navigation Menu:

- a. My Apps: Consist of the list of applications installed in the box.
- b. Home Player: This feature enables user to view images or videos and play audio through a Pendrive or a memory card.
- c. Settings: Consist of a list of settings for the device as shown below



- i. Network: This section consist of details about the Ethernet and WiFi connectivity of the device.
- ii. Time and Date: This section consist of the settings of the Time zone, the date and time format and also lets the user to choose the option of auto updating the Date and time of the device.
- iii. Sound: Consists of a list of settings for the Sound of the device
- iv. Display: Consists of settings for the display of the device.
- v. Storage: Consists of details of any storage media connected to the set top box.
- vi. Language: Consists of options of selecting languages to be used in the device.
- vii. Device information: Consists of the details of the build of the set top box.
- viii. Factory Reset: Consists of options to factory reset the device or clear the cache memory.
- ix. System Update: This lets the user to update the system of the device, if an update is made available.
- d. Refresh: This option can be used to refresh the set top box.

6.1 Live TV



a. Live TV Channels Category: This consists of different categories such as English News, Music and Movies, Hindi and Punjabi, Pakistani, Nepalese, Bengali, International, Sports, etc and a list of channels that fall under each category.

b. EPG/DVR feature: This feature provides you the option to view the program schedule of a particular channel in the form of an Electronic Program Guide. Digital Video Recording (DVR) feature is also available where you can watch previously recorded TV programs.

c. Set/ Unset Fav: User can set/unset a channel as his/her favorite channel according to their preferences. A star icon will be seen beside the channel when the channel is set as fav, and will disappear once it is unset as fav. A new Favorite category is also seen once any channel is marked as a favorite channel.

d. Buy/Free/Bought: Indicates if the channel is available for free, has been bought or needs to be bought.

e. Preview: An option to On/Off preview is given to the user. If the preview is turned on, when focus is set on any other channel without playing it, a preview can be seen on the bottom-right corner of the screen. This enables the user to get a sneak-peek of a channel without having to actually play it.

f. Quick Menu: On pressing the OK button on the remote, when any channel is playing, without the menu being displayed, a quick menu, with all the channel categories and channel listing can be seen on the screen. This provides easier access to the Live TV channels.

6.2 Movies

You can watch different genre of movies in this section. You can also parentally lock the movies that you do not want your children to watch.

Both free and premium movies are available to watch as per user's choice. Users are also facilitated by the Pay per View feature in World on Demand.

6.3 TV Shows

This section consist of some YouTube channels and some featured TV shows. This is a Video on Demand service.

6.4 YouTube Plus

This section consist of useful YouTube channels from where people can learn and stay updated to new channels and videos. Multiple YouTube channels can be accessed from here.


6.5 Video Chautari

This feature includes all the on demand Nepalese videos of different genre.

6.6 Highlights Nepal

This feature allows you to watch Movies, Songs and Videos published by the popular movie distributor and YouTube channel Highlights Nepal.


6.7 My Account



a. Dashboard : This consists of the details about the user's account including user's current balance, User info and the details about the various packages.

b. Packages: This section consists of the details about the packages the user has bought and also consist of the various TV and Movie packages that are available.

c. Top Up:



The user can top up balance into their World on Demand account via WOD scratch cards, Paypal or Credit cards.

d. Preferences: The user can choose to set screensaver, or pin, according to his/her preferences.

e. Purchase history: This consist of a list of purchases the user has made till date.

7. Detailed Description Of Remote



- Power
- Return
- Mouse
- Menu
- Home
- Settings
- Mute
- Volume
- Channel



Navigation

Press to navigate left/right/up/down and OK to confirm.



Controller



Numpad



TV section with the power button:

Map the buttons to control your Television. This remote can be used as a Universal remote by following the steps listed below :

1. Press the Set key on set top box for 5second until the LED keep red lighting
2. Press the volume down key ,the red led light will be flash
3. Hold pressing remove volume down key and press the v_ key on the tv remote controller as well.. release hold on stb remote but keep pressing on tv remote until the red light is off.



TV Control Area

All the launcher applications can be easily accessible from here.

8. Payment Method:

A user has to top up balance into his/her World on Demand account in order to purchase premium contents, be it TV channels or Movies. Balance can be topped up into the account through World on Demand scratch cards, Credit Cards or PayPal. A user can also top up balance through our website, <https://worldondemand.net/> and enjoy premium contents.

9. How do I connect WiFi to the World on Demand STB?

To connect WiFi in the World on Demand STB, please follow the steps listed below:

- a. Disconnect the LAN cable (Ethernet) connected to the set top box.
- b. Navigate to Settings through the Side navigation menu of the Launcher
- c. Select Network settings
- d. Navigate to the WiFi option and turn it on
- e. Select the desired WiFi network.

10. General Troubleshooting Tips

If none of the apps are being able to open because of Memory Problem :
Press the Refresh Button shown in the side navigation menu of the Launcher. This will clear the cache memory.
Alternatively you could also Go to Settings > Factory Reset > Clear Cache.

For Factory Reset

Go to Settings > Factory Reset > Choose Factory reset

It might take some time to reset. Therefore you might have to wait for some time till the factory reset is processed and the box is rebooted.

If Date and time displayed in the launcher is not correct

Go to Settings > Time and Date > Select Correct Time zone and Format



Email: info@newitventure.com
www.worldondemand.net
Tel: +81-3-5650-5430

HEAD OFFICE

NEW IT VENTURE CORP.,
Kopo Yamato Bldg 1F & 2F
Tateishi 5-24-8, Katsushika-ku,
Tokyo 124-0012, JAPAN
Tel : 03-5650-5430
Email: sales@newitventure.com

SALES OFFICE

NEW IT VENTURE CORP.,
Shinjuku Sales Office
Omori Bldg 1F
Hyakunincho 1-10-7,
Shinjuku-ku, Tokyo 124-0012, JAPAN
Email: sales@newitventure.com